Installation

P/N: CL-R0026


Spirit RS


Application for DDR, DDR2 Memory

Parts List

Tem	Name	Photo	Q"ty	Tem	Name	Photo	Q"ty
Α	Heatpipe Module		1	D	Thermal Pad (2 Types,thin and thick)		Thin: 2 Thick:2
В	Aluminum Heatsink		2	E	Thermal Grease		1
С	Screw		4	F	Hexagon spanner		1


Exploded View






Installation

• Loosen the screws (C) on each side of heatsink by using hexagon spanner (F) and separate the heatpipe module (A) and heatsink (B).




- Paste the thermal pad (D) onto each side of memory module.
 - A. For single sided memory module, please use thick thermal pad.
 - B. For double sided memory module, please use thin thermal pad.



• Apply a thin layer of thermal grease (E) on the heatpipe, and secure the heatsink(B), heatpipe module(A) on to the RAM. (See Complete View)

Completed View



Note: Angle for the Heatpipe module is adjustable, You may adjust it to the most suitable angle to avoid any possible interference.



